



## Parts List for TS410 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	580151-01	CLAMSHELL SET	1
3	000000-00	No Longer Available	1
5	368329-01	BOARD,CIRCUIT	1
6	770235	CORD PROTECTOR	1
7	330073-98	CORD/8 FT/18-2	1
8	000000-00	No Longer Available	1
9	370282-00	LOCK	1
10	748158-00	SPRING	1
11	370966-00	WASHER	2
14	832457-00	BRUSH & HOLDER	2
15	830393-00	LEAD,BOT.SWITCH	1
16	372828-00	LEAD	1
18	369620-00	NUT	1
19	000000-00	No Longer Available	1
20	368562-00	GEAR	1
21	812171	SCREW	6
23	810897-00	BEARING,SLEEVE	1
24	368465-00	SHAFT	1
25	810893-00	BEARING,SLEEVE	1
26	847216-00	SEAL	1
27	330041-11	PIN	2
28	368382-00	CLAMP	1
29	797123-00	SCREW	2
30	000000-00	No Longer Available	1
30	000000-00	No Longer Available	1
31	369008-00	GUARD	1

## Parts List for TS410 Type 1

Item Number	Part Number	Description	Qty Required
32	370584-00	GUARD	1
33	000000-00	No Longer Available	1
34	000000-00	No Longer Available	1
35	368857-00	CLAMP	1
36	376409-00	SCREW	2
37	369304-00	SHOE	1
38	000000-00	No Longer Available	1
39	5103541-00	SCREW	8
55	368608-00	ADAPTER,VACUUM	1