



## ELECTRIC TOOL PARTS LIST

**CORDLESS RADIO**  
**Model UR 18DSAL**

**2015-3-31**  
**(E1)**





**PARTS**

UR 18DSAL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
1	338364	TAPPING SCREW (W/FLANGE) D2 X 8	12	
2	338392	ADAPTER STORAGE CASE	1	
3	338399	TAPPING SCREW (W/FLANGE) D2.3 X 8	19	
4	338409	SQUARE WASHER	11	
5	338365	BATTERY COMPARTMENT SET	1	
6	338398	MACHINE SCREW (W/FLANGE) M3 X 8	9	
7	338374	CONNECTOR A	1	
8	338397	TAPPING SCREW D4 X 18	7	
9	338390	RUBBER ANTENNA	1	
10	338363	LOWER BACK COVER BUTTON	1	
11	338362	UPPER BACK COVER BUTTON	1	
12	338361	BACK COVER LATCHING B	1	
13		NAME PLATE	1	
14	338360	BACK CABINET SET	1	INCLUD.1,10-12
15	338388	UPPER CONTACT BRACKET	1	
16	339154	BATTERY TERMINAL	1	
17	338389	LOWER CONTACT BRACKET	1	
18	338407	INTERNAL WIRE (B)	1	
19	338405	CONNECTOR C	2	
20	338387	BATTERY COVER	1	
21	338410	SCREW M3	1	
22	338394	DC JACK BRACKET	1	
23	339155	RUBBER SHEET (DC JACK)	1	
24	338396	DC JACK	1	
25	338404	CONNECTOR B	1	
26	338372	CABLE HOLDER (ANDROID)	1	
27	338385	SUPPORT	1	
28	338366	BRACKET SET	1	INCLUD.29
29	338400	TAPPING SCREW D2 X 6	6	
30	338383	LEFT LATCHING	1	
31	338378	LEFT LATCH MOUNTING	1	
32	338384	RIGHT LATCHING	1	
33	338379	RIGHT LATCH MOUNTING	1	
34	338386	LATCHING PLATE	1	
35	338408	PCB ASS'Y (USB)	1	
36	338403	PCB PLATE	1	
37	339113	TAPPING SCREW D1.7 X 10 (10 PCS.)	4	
38	338391	PCB ASS'Y (AUX)	1	
39	338371	CABLE HOLDER (APPLE)	1	
* 40	338424	PCB ASS'Y (A)	1	
* 40	338425	PCB ASS'Y (A) AUS	1	FOR AUS
* 40	338426	PCB ASS'Y (A) USA,CAN	1	FOR USA,CAN
41	338402	SPEAKER RESISTANCE STRIP	2	
42	338421	SPEAKER (DSAL)	2	
43	339115	WATER RESISTANCE STRIP E	2	
44	338401	TAPPING SCREW D2 X 8	2	
45	338377	SIDE PLATE	2	
46	338370	SPEAKER GRILL SET	2	
47	949553	NUT M3 (10 PCS.)	8	
48	949811	HEX. SOCKET HD. BOLT M4 X 8 (10 PCS.)	6	

**PARTS**

UR 18DSAL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
49	338367	FRONT COVER SET	1		
*	50	BLUETOOTH LABEL	1	FOR USA,CAN	
*	51	338415 FRONT CABINET SET B	1		
*	51	338416 FRONT CABINET SET C	1	FOR USA,CAN	
52	338406	CONNECTOR D	1		
71	323041	MACHINE SCREW M5 X 30 (BLACK)	6		
72	302012	NUT M5 (BLACK)	6		
73	338417	DSAL FRAME (A) OUTER	3		
74	338418	DSAL FRAME (A) INNER	3		
75	339117	SPONGE (F)	6		
76	339114	RUBBER WASHER	6		
77	338422	TAPPING SCREW D3 X 8	18		
78	339116	NUT PLATE	6		
79	338420	DSAL FRAME (B) OUTER	2		
80	338419	DSAL FRAME (B) INNER	2		
81	302196	MACHINE SCREW M5 X 20 (BLACK)	6		

**STANDARD ACCESSORIES**

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
*	501	338412 AC-ADAPTER (EURO)	1		
*	501	338414 AC-ADAPTER (AUST)	1	FOR AUS,NZL	
*	501	338427 AC-ADAPTER (USA)	1	FOR USA,CAN	
	502	AA BATTERY	2		