



Blower UT-08120-B 08120-B-UT Blower UT-08120-B Blower - Carburetor And Fuel Tan



Ref #	Part #	Description	Qty
1	984907001	FUEL TANK KIT	1
2	A09116	FUEL TANK CAP	1
3	08684	HEAT SHIELD	1
4	98792	RUBBER BUMPER	3
5	985232001	CARBURETOR KIT	1
6	985304001	INLINE FUEL FITTING	1
7	0143912	RUBBER TUBBING (3 in)	1
8	983925001	CARBURETOR GASKET	1
9	00775A	HEAT DAM GASKET	1
10	04474	SCREW (10-24 x 2-1/4 in Hex Hd)	2
11	98768A	HEAT DAM	1
12	093221	USE 660662001	2
13	985077001	FUEL FILTER KIT	1


Blower UT-08120-B 08120-B-UT Blower UT-08120-B Blower - Ignition And Rotor



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	985122001	IGNITION KIT WITH MODULE	1
2	PS02227	SPARK PLUG	1
3	82540	SCREW (8-32 x 1 in. TORx pan Hd.)	2
4	986152001	ROTOR AND STARTER PAWLS	1
5	95479A	FLAT WASHER	1
6	PS02566	FAN SPACER	1


Blower UT-08120-B 08120-B-UT Blower UT-08120-B Blower - Internal Engine



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	983928001	SHORT BLOCK (30cc)	1
2	985524002	30cc CYLINDER	1
3	985259001	CYLINDER GASKET	1
4	PS02807	SCREW (12-24 x 3/4 in. TOR x pan Hd.)	3
5	986119001	30cc PISTON ASSEMBLY	1
6	03179	PISTON RING	2
7	PS02130	CRANKCASE COVER	1
8	06443A	CRANKCASE GASKET	1
9	PS01565	SCREW (10-24 x 9/16 in. pan Hd.)	4
10	82376	SCREW (#8 x 1/2 in. pan Hd.)	3
11	82563	SCREW (#10 x 3/4 in. TORx TRUSS Hd.)	1
12	PS06314	SHROUD	1
13	983924001	ZIP START DECAL	1


Blower UT-08120-B 08120-B-UT Blower UT-08120-B Blower - Muffler And Air Cleaner



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	985912001	MUFFLER COMPLETE (UT08120B)	1
2	09217	AIR FILTER BOX	1
3	81208	HEX NUT (10-24)	2
4	98760	AIR FILTER	1
5	09218	AIR FILTER COVER	1
6	983904001	CHOKE DECAL	1


Blower UT-08120-B 08120-B-UT Blower UT-08120-B Blower - Starter



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	983864001	THROTTLE LATCH	1
2	00370	THROTTLE LATCH SPRING	1
3	00367	THROTTLE TRIGGER	1
4	00369A	THROTTLE LEVER	1
5	82538	SCREW (10-24 x 3/4 in TRUSS Hd)	4
6	JA416903	SCREW (10 x 1-5/8 in Hex Hd)	1
7	00374	ROTOR PLATE	1
8	82528	SCREW (#6 x 1 3/8)	1
9	5946702	STARTER GRIP (YELLOW)	1
10	969811A	BUSHING STARTER	1
11	00364B	STARTER ROPE GUIDE	1
12	A98773A	SPRING AND CONTAINER	1
13	98770A	STARTER PULLEY	1
14	98791	RETAINING BRACKET	2
15	82541	SCREW (10-24 x 1/2 in TORx TRUSS Hd)	3
16	9789901	STARTER ROPE	1
17	PS82146	SCREW (8-32 x 5/8 in FIL Hd)	1
18	82563	SCREW (10-14 x 3/4 in TORx TRUSS Hd)	5
19	PS03167	INNER VOLUTE HOUSING	1
20	983856001	THROTTLE CONTROL KNOB	1

Blower UT-08120-B 08120-B-UT Blower UT-08120-B Blower - Volute, Fan And Tubes



Ref #	Part #	Description	Qty
1	00372B	UPPER TUBE	1
2	82541	SCREW (10-24 x 1/2 in. TOR x TRUSS Hd)	2
3	00373A	LOWER NOZZLE	1
4	983906001	CLAMP WITH FASTENERS	1
5	983857002	OUTER VOLUTE HOUSING	1
6	983861001	DOOR	1
7	00398	WIRE LOOP	1
8	985738006	HEX NUT (3/8-24)	1
9	984911001	BLOWER FAN KIT	1
10	03165	FLAT WASHER	1
11	984921001	DOOR YARD BROOM DECAL	1
12	983901001	WARNING DECAL	1
13	983902001	OUTER VOLUTE DECAL	1
14	983912001	FAN INTAKE DECAL	1
15	617205001	SCREW (1/4-20)	1
	983000254	OPERATORS MANUAL - UT08120	
	983000655	OPERATOR'S MANUAL (MODEL UT08120d)	
	983000-254R	REPAIR SHEET (MODEL UT08120B)	
	983000655R	REPAIR SHEET (MODEL UT08120d) (Rev01)	