


Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	678726003	Vacuum Door Spring	1	
2	940654088	Warning Label (Combustion)	1	
3	521500008	Vacuum Door	1	
4	660621001	Vacuum Tube Screw (10-14 x 1/2 in., T25 Torx Truss Hd. T.F.)	4	
5	970694003	Vacuum Bag w/Shoulder Strap	1	
6	941727004	Warning Icon Label	1	
7	940705301	Logo Label (Small)	1	
8	870174002	Spark Plug (Champion RCJ6Y)	1	
9	563747002	Filter	1	
11	940868001	Choke Label	1	
12	940734163	Starting Label	1	
13	310804004	Air Filter Cover	1	
14	590461006	Knob	1	
15	521504002	Vacuum Handle	1	
16	650027001	E-ring (Retaining Ring)	2	
17	660880001	Screw (1/4-20 x 3/4 in., Soc. Hd.)	2	
18	580892002	Upper Vacuum Tube	1	
19	570562002	Lower Vacuum Tube	1	
20	580956001	Vacuum Bag Adaptor	1	
21	360152003	Blower Tube Assembly	1	
22	580613006	Wet Leaf Nozzle	1	
23	940680052	Hot Surface Label	1	
24	941727009	Tube Removal Label	1	
	991000662	Operator's Manual		



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context	Note
1	660629002	Screw (#10-14 x 3/4 in, T25 Torx Pan Hd. T.F.)	12		
2	351258001	Outer Volute w/Labels	1		
3	660561007	Lock Nut (3/8 in.)	1		
4	678126005	Washer (ID9.8 x OD30 x 3t)	1		
5	518265003	Fan	1		
6	638517001	Spacer	1		
7	660970001	Screw w/Washer (M4 x 16 mm, T25 Torx Truss Hd.)	4		
8	660666001	Cruise Lever Screw (M8-14 x 25 mm, Special T20 Truss Hd.)	1		
9	678125001	Washer (ID 4.3 x OD12 x 1.5t)	1		
10	518160007	Cruise Control Lever	1		
11	351259002	Inner Volute w/Eyelet w/Label	1		
12	518603002	Throttle Lever	1		
13	661141001	Screw (M3.5 x 7.5 mm, T20 Torx Pan Hd.)	1		
14	521503002	Throttle Trigger	1		
15	518602001	Trigger Lock	1		
16	760961002	Stop Switch (Momentary Contact)	1		
17	290157002	Wire Assembly (UT26HBV)	1		
18	270031002	Throttle Cable	1		
19	521501003	Handle Cover	1		
20	660466001	Screw (M4 x 18 mm, T20 Torx Pan Hd. S.T.)	5		
21	660968001	Screw w/Washer (M4 x 19 mm, T20 Torx Pan Hd. S.T.)	2		
22	311020006	Ignition Module and Flywheel Kit (UT26HBV)	1		
23	312875001	Lower Housing w/Starter and Label	1		
24	900849012	Starter Rope (42 in.)	1		
25	525485001	Pulley Handle	1		
26	638088004	Eyelet	1		
27	521535013	Shield	1		
28	638033001	Spring & Container Assembly	1		
29	521316001	Starter Pulley	1		
30	638389001	Pulley Retainer	3		
31	660967001	Screw (M4 x 14 mm, T20 Torx Truss Hd T.F.)	3		
32	650017002	Washer (ID9.70 x OD20 x 1.59t)	1		
33	901551001	Inner Heat Dam Gasket	1		
34	308892033	Short Block Assembly	1		
35	312758004	Engine Cover w/Labels	1		
36	901362003	Muffler Gasket	1		
37	309327009	Muffler Assembly	1		
38	638442009	Muffler Heat Shield	1		
39	660638003	Screw w/Washers (10-24 x 2-1/8 in., T25 Torx Truss Hd.)	2		
40	660454006	Bolt (M5 x 48 mm, T20 Torx hd.)	2		
41	534838001	Heat Dam	1		
42	638659002	Washer (ID5 x OD10.9 x 0.5t)	1		
43	660927003	Screw (M5 x 25 mm, T20 Torx Hd.)	2		
44	310816015	Fuel Cap Assembly (Inc. Tether)	1		
45	901552006	Heat Dam Gasket	1		
46	308054111	Carburetor	1		

Ref #	Part #	Description	Qty	Context Note
47	561635001	Primer Bulb (Ruixing)	1	
48	290469001	Ground Wire Assembly	1	
49	521309006	Air Box Base	1	
50	638911001	Washer	1	
51	901550003	Crankcase Cover Gasket	1	
52	638337005	Crankcase Cover	1	
53	660925003	Screw (M4 x 12 mm, T20 Torx Hd.)	6	
54	310753016	Fuel Tank Assembly (Inc. Fuel Lines)	1	
55	660970002	Shoulder Screw w/Washer (M4 x 14 mm, T25 Torx Truss Hd.)	3	
56	310976001	Fuel Filter	1	
57	521535010	Baffle Plate	1	