

UT905000P 5000 Watt Generator - Figure A




FIGURE A /
FIGURA A

Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context	Note
1	661603001	Bolt (M5 x 10 mm, Flange Hex Hd.)	2		
2	678296002	Brush Cover	1		
3	660869006	Bolt (M6 x 164 mm)	4		
4	661603002	Bolt (M5 x 16 mm, Flange Hex Hd.)	3		
5	290441001	Brush Assembly	1		
6	290440008	Automatic Voltage Regulator	1		
7	638128002	Washer (5/16 in.)	1		
8	661557009	Bolt (5/16-24 x 215 mm, Hex. Hd.)	1		
9	660596002	Bolt (3/8-18 x 1-1/4 in.)	4		
10	640331002	Engine Adapter	1		
11	678289008	Bearing Support	1		
12	290455002	Bonding Wire	1		
13	310771015	Rotor Assembly	1		
14	310772014	Stator Assembly	1		
15	638624006	Generator Head Cover	1		
16	661603010	Bolt (M5 x 75 mm)	2		
17	678263001	Lock Washer (M5)	2		
	570766002	Rubber Boot	1	Not Shown	
	900333015	Wire Tie	1	Not Shown	

UT905000P 5000 Watt Generator - Figure B




FIGURE B /
FIGURA B

Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	310711053	Fuel Tank	1	
2	310720026	Fuel Tank Cap	1	
3	678408006	Fuel Line Clamp (1/2 in.)	6	
4	570358032	Fuel Line (105 mm)	2	
5	308733001	Fuel Filter	1	
6	308459002	Fuel Shut Off Valve	1	
7	570358031	Fuel Line (208 mm)	1	
8	518528002	Spacer (Fuel Tank Isolator)	4	
9	519832003	Bushing (Fuel Tank Isolator)	4	
10	638711002	Bushing	1	
11	310854001	Rollover Valve	1	
12	570466002	Rollover Hose	1	

UT905000P 5000 Watt Generator - Figure C





FIGURE C /
FIGURA C

Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	660958001	Screw (6-20 x 3/8 in.)	10	
2	570412001	Outlet Cover (240 Volt)	1	
3	570412002	Outlet Cover (120 Volt)	2	
4	678810002	Hex Nut (1/4-20)	2	
5	678720001	Nut (M6-32)	6	
6	638496004	Cover Plate	1	
7	661503011	Screw (1/4-20 x 5/8 in., Hex Hd.)	1	
8	290400008	Duplex Receptacle (120 Volt)	2	
9	780350001	Circuit Breaker (20 Amp, 125 Volt)	2	
10	290400007	Twist Lock Receptacle (120/240 Volt, 20 Amp)	1	
11	519707001	Rear Control Panel	1	
12	678824001	Rubber Boot	1	
13	940780040	Control Panel Label	1	
	310714025	Panel Assembly	1	(Key 1-10, 12 and 13)

UT905000P 5000 Watt Generator - General Assembly




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	310227016	Generator Head w/AVR	1	(Inc. Key No. 48) Homelite Consumer Products, Inc., will not provide engines as replacement parts. Engines are covered through the engine manufacturer's warranty. Consult the accompanying engine manual or contact our service department for assistance.
2	940678217	Data Label	1	
3	308444002	Back Panel Assembly	1	
4	308451010	Wheels	2	
5	678074002	Lock Nut (1/4-20)	16	(Inc. Key No. 62)
6	678238001	Hitch Pin	2	
7	661400003	Bolt (1/4-20 x 42.5 mm, Torx Hd.)	18	
8		Engine (EX30 Subaru)	1	
9	638128004	Washer (1/4 in.)	4	
10	308449003	Handle Release Pin Assembly	1	
11	678823001	Lock Washer (M6)	18	
12	519812004	Frame Slide Rails	2	
13	678016007	Hex Nut (1/4-20)	6	
14	678016006	Lock Nut (1/4-20)	6	
15	660598001	Screw (6-20 x 3/8 in., Pan Hd.)	4	
16	940872003	E-85 Label	1	
17	660901015	Bolt (1/4-14 x 1.25 in., Hex Hd.)	4	
18	660962001	Bolt (M8 x 55 mm, Hex Hd.)	2	
19	678774001	Lock Nut (M8)	2	
20	519712001	End Cap	4	
21	310224015	Handle Assembly	1	
22	940707089	Danger Label	1	
23	940513008	Ground Warning Label	1	
24	940040017	Logo Label	1	
25	638700015	Control Panel	1	
26	940515016	CPSC Label	1	
27	290403017	Control Box (Front and Rear Assembly)	1	

Ref #	Part #	Description	Qty	Context Note
28	308581012	Frame Assembly	2	
29	638493007	Frame Cross Brace	2	
30	638236010	Back Frame Bracket	1	
31	661400004	Bolt (1/4-20 x 2 in., T30 Torx Hd.)	4	
32	638706006	Foot	2	
33	570554001	Wear Pad	2	
34	310711051	Fuel Tank Assembly	1	
35	661503001	Bolt (1/4-20 x 1 in., Hex Hd.)	2	
36	310739004	Foot Assembly	2	
37	660591006	Bolt (5/16-18 x 1-1/2 in.)	4	
38	638678002	Lock Washer (5/16)	4	
39	570356001	Isolator (Generator)	4	
40	678145002	Flange Nut (5/16-18, Hex Hd.)	5	
41	940680021	Hot Surface Label	1	
42	940947003	Combustion Label	1	
43	940708007	Lubricant Label	1	
44	940974007	Fire Danger Label	1	
45	940514007	Pin Release Label	1	
46	661502005	Bolt (5/16-18 x 3/4 in.)	1	
47	638704001	Star Washer (5/16 in.)	2	
48	940705111	Back Panel Logo Label	1	
49	290404001	Ground Wire Assembly	1	
50	940617032	Starting Instruction Label	1	
51	309322010	Muffler	1	
52	661306001	Spark Arrestor Screw	4	
53	638147003	Spark Arrestor	1	
54	660599002	Bolt (5/16-24 x 5/8 in.)	2	

Ref #	Part #	Description	Qty	Context Note
55	638499003	Muffler Gasket	1	
56	638581001	Washer (5/8 x 1 x 5/8 in.)	2	
57	570371003	Rubber Handle Bumper	2	
58	940971058	Danger Hang Tag	1	
59	638539002	Back Muffler Cover	1	
60	620599011	Axle	2	
61	638387005	Washer (1/4 in.)	6	
62	638356001	Washer (OD20 x ID8 x 1t)	1	
	988000478	Operator's Manual	1	

UT905000P 5000 Watt Generator - Wiring Diagram



WIRING DIAGRAM /
SCHÉMA DE CÂBLAGE / DIAGRAMA DE CABLEADO Rendered by LeadVenture, Inc.