


XL98E Multi Purpose Saw UT-05060 05060-UT XL98E Multi Purpose Saw UT-05060 XL98E Multi Purpose Saw - Air Cleaner - Throttle Handle




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	86324	COTTER PIN	1
2	672011	CHOKE ROD	1
3	63266A	ROD - Throttle	1
4	58348	BOOT - Throttle Rod	1
5	63369A	SCREW - Idle Adjustment	1
6	81117	NUT - Jam (5/16-24)	1
7	80676	SCREW - Hex hd (12-24 X 5/8")	1
8	80891	SCREW - Hex hd (12-24 X 7/8")	1
9	88049	SCREW - (10-24 X 1/2")	1
10	496861	PAD - Wear	1
11	A01845	HANDLE - Throttle	1
12	68767	GRIP - Throttle Handle	1
13	64862	GROMMET	1
14	A69045A	COVER - Throttle Handle	1
15	59064	BUSHING	1
16	58859A	TRIGGER	1
17	58409	RING - Retaining	1
18	68548	PIN - Trigger	1
19	58405	SPRING - Throttle lock	1
20	95671	PIN - Throttle	1
21	68768	GRIP - Throttle Handle	1
22	80560	SCREW - Pan hd (8-32 X 1/2")	2
	A49556C	AIR FILTER KIT	1
23	A50952B	RING & GASKET ASSY	1
24	50951	GASKET	1
25	49786	FILTER - Air	1
26	49213	PRE FILTER - Felt	1
27	546208	ELEMENT - Air Filter	1
28	49212	COVER - Filter Element	1
29	81162	NUT - Hex (5/16-18)	1
30	A49687	DECAL - Warning	1
31	06365	KNOB - Handle	1
32	02762A	GASKET	1
33	49263	DECAL - Instruction	1

Ref #	Part #	Description	Qty
34	A02786	BRACKET - Cover	1
35	88042	SCREW	4
36	46072	GASKET	1
37	800232	SCREW - (8-32 X 5/8")	1
38	65745	TRIGGER	1
39	65719	PIN	1


XL98E Multi Purpose Saw UT-05060 05060-UT XL98E Multi Purpose Saw UT-05060 XL98E Multi
Purpose Saw - Carburetor



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
16	63779C	GASKET	1
17	63370A	RETAINER - Reed	1
18	63166A	REED - Valve	4
19	63371B	SEAT - Reed Valve	1
20	65483	GASKET	1
21	A674601	SPACER - Carburetor	1
22	82570	SCREW - (8-32 X 1 1/4")	2
23	82540	SCREW - Thread form (8-32 X 1 1/4")	1
24	9311252	FUEL LINE	1
25	A07156	CARBURETOR	1
26	67540	GASKET	1
27	69751	GROMMET	1
28	82179	SCREW - (10-32 X 1 7/8")	2
29	83046	WASHER - Lock	2

XL98E Multi Purpose Saw UT-05060 05060-UT XL98E Multi Purpose Saw UT-05060 XL98E Multi Purpose Saw -
Engine Internal - Fuel Tank



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	A08335	CRANKCASE	1
2	69438	STUD - Cylinder	4
3	03027	SPACER - Fuel Tank	1
4	03026A	SPACER - Fuel Tank	1
5	02327	BOLT - (5/16-18 X 2 1/4")	1
6	82595	BOLT - (5/16-18 X 2 1/2")	1
7	12306	SEAL	1
8	64156A	SAW DUST SHIELD	1
9	46788A	DECAL - Instruction/Warning	1
10	A03498A	FUEL TANK	1
11	A97700	USE UP06516	1
12	592531A	ELEMENT - Filter	1
13	931125B	TUBING - Rubber (13")	1
14	A00982B	CAP - Fuel	1
15	98805A	GASKET - Fuel	1
16	67559	"O" RING	1
17	58319A	NLA(NO LONGER AVAILABLE)	1
18	58190	BEARING - Ball	1
19	59705	WASHER - Lock	2
20	70306	SCREW - Torx	2
21	75078	KEY - Woodruff	1
22	671684	CRANKSHAFT	1
23	A69056	NLA(NO LONGER AVAILABLE)	1
24	A69658A	ROD - Connecting	1
25	69919	SCREW - Hex Hd. (8/32 X 1/2")	2
26	69638A	BEARING	1
27	68010	WASHER	2
28	A49314	PIS TBO	1
29	64742	RING - Retaining	2
30	55537	PISTON RING	1

Purpose Saw - Handle - Clutch




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	80891	SCREW - Hex hd (12-24 X 7/8")	2
2	698292	BRACKET - Handle bar	1
3	51163	MOUNT - Shock (bracket)	1
4	804281	SCREW - Nylock (1/4-20 X 1")	3
5	A49927	HANDLE BAR	1
6	80939	SCREW - Pan hd	1
7	95935	WASHER	1
8	81225	NUT - Hex 12-24	2
9	A08335	CRANKCASE	1
10	93628	COVER - Clutch	1
11	A69480C	CLUTCH ASSEMBLY	1
12	67053	SPRING - Clutch	3
13	657601B	PLATE - Clutch	1
14	59933	WASHER - Thrust (Inner)	1
15	A49224	PULLEY(XL-98C)	1
16	51151	BEARING - Needle	1
17	A97901A	INNER RACE KIT	1
18	81282	NUT - Hex Flange (5/16-18)	1
19	535797	COVER - Drivecase	1

Ref #	Part #	Description	Qty
	A69864C	COMPLETE MUFFLER	
1	95885	SCREW - Hex Hd	1
2	82280	SCREW - Hex Hd (1/4-20 X 3")	2
3	69842	SHIELD - Muffler	1
4	A698361	CAP - Muffler	1
5	69844	SUPPORT - Short	1
6	69843	SUPPORT - Long	1
7	A93900A	SCREEN - Spark Arrestor	1
8	69839	PLATE Muffler	1
9	A698381	BODY - Muffler	1
10	78098	GASKET - Muffler	1
11	93561S	SPARK PLUG	1
12	96212	NUT - (1/4-28 X 3/8")	4
13	83009	WASHER - Lock (1/4")	4
14	A42206B	CYLINDER	1
15	637781	GASKET - Cylinder	1


XL98E Multi Purpose Saw UT-05060 05060-UT XL98E Multi Purpose Saw UT-05060 XL98E Multi Purpose Saw -
Starter - Ignition



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	825551	SCREW - Th Hd. (10-24 X 3/4") Torx (T25)	3
2	A03619A	HOUSING - Starter w/bushing	1
3	67177	BUSHING	1
4	A69962B	GRIP - Starter	1
5	70018A	INSERT	1
6	A98067	SPRING & RETAINER	1
7	84025	WASHER - Flat	2
8	82528	SCREW - Thd. Form. (6-32 X 3/8")	2
9	A97990C	PULLEY & CUP	1
10	A00518	STARTER ROPE	1
11	02505	SPRING - Grip	1
12	97992A	BUSHING - Starter Rope	1
13	58763	WASHER - Flat	1
14	82409	SCREW - (10 7/8")	1
15	81124A	NUT - Hex (3/8-24)	1
16	83102	WASHER - Lock (3/8")	1
17	84010	WASHER - Flat (3/8")	1
18	88044	SCREW - Sems Hex hd (8-32 X 1")	2
19	A96798A	MODULE - Ignition	1
20	96743	LEAD - High Tension	1
21	A94850	NLA(NO LONGER AVAILABLE)	1
22	A33055	TERMINAL HIGH TENS(P TBO	1
23	A576503B	SWITCH - Grounding	1
24	72084A1	NUT	1
25	12793A	PLATE - Indicating	1
26	80052	SCREW - Sems Hex Hd (1/4-20 X 3/4")	1
27	63195	BEARING - Roller	1
28	12283A	SEAL	1
29	A96799A	PLATE - Back	1
30	80049	SCREW - (1/4-20 X 5/8")	1
31	96801A	ROTOR	1
32	01101	SPRING - Starter Pawl	1
33	84115	WASHER - Flat	1
34	58756A	STARTER PAWL	1
35	64054C	SCREW - Shoulder	1
36	96176	SCREW - Th Hd (10-24 X 1 625) Torx (T25)	2

XL98E Multi Purpose Saw UT-05060 05060-UT XL98E Multi Purpose Saw UT-05060 XL98E Multi Purpose Saw -
Wheel Arm Assembly



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty
1	A00660	KNOB & PIN	1
2	966201	SCREW - Truss Hd. (10-24 X 1/2")	1
3	01923	PLATE - Spring	1
4	01922	SPACER - Adjusting Pin	1
5	JA461359	PIN - Roll	1
6	01921	SLEEVE - Cam	1
7	95792	SCREW - Round Hd (10-24 X 23/32")	3
8	07704	BELT - Cover	1
9	02423	NUT - Hex	1
10	JA446148	WASHER - Lock (7/16)	1
11	46068	BELT - V-Drive	1
12	A02891	PULLEY & HUB	1
13	076563A	ARM - Wheel	1
14	02267	SNUBBER	1
15	00568	STEEL BALL	1
16	63107	BEARING - Ball	2
17	01916	SPACER - Bearing	1
18	31746	RING - Retaining	1
19	019061	SHAFT - Wheel	1
20	01915	COLLAR - Wheel Guard	1
21	01914A	PAD - Adjuster	1
22	01913	DETENT - Adjuster	1
23	A04647A	WHEEL GUARD & DECAL / 1/2"	1
24	04645A	DECAL - Caution	1
23	A07696A	WHEEL GUARD & DECAL / 14"	1
24	04645A	DECAL - Caution	1
25	01912	WASHER - Rubber	1
26	0191101	SHIM - .020"	1
26	0191102	SHIM - .030"	0
27	01910	WASHER - Spring	1
28	95935	WASHER (#12-11/16)	3
29	966201	CREW - Truss Hd (10-24 X 1/2")	3
30	019091A	FLANGE - Wheel	1
31	01902	SPACER (1")	1
	01903	SPACER (22mm)	1
	01907	SPACER (20mm)	1
32		WHEEL	1
33	A03412	BOLT & WASHER	1
34	80087	CREW - Hex hd (5/16-18 X 1 1/2")	1
35	A49194	USE UP03371	1