



ORDER BY PHONE: 1-800-241-5640

KEY	PART NO.	DESCRIPTION
1	PA37040	FASTENER GUIDE ASSEMBLY
1A	100227	MAGNETIC FASTENER GUIDE ASSM (NOT SHOWN)
2	100167	PISTON RETURN SPRING (PKG OF 2)
3	010983	PISTON BUFFER/INSULATION RING (PKG OF 2)
4	PA37037	PISTON
5	PA37021	POWER ADJUSTMENT ASSEMBLY
6	PA37007	BARREL ASSEMBLY
7	010975	STOP RING KIT
8	PA37015	COCKING ROD KIT
9	PA37016	CHARGE ADVANCE LEVER ASSEMBLY
10	PA37003	RUBBER GRIP
11	PA37001	OUTER HOUSING ASSEMBLY (L & R)
12	N/A	RECEIVER ASSEMBLY
13	PA37009	OUTER HOUSING SCREWS (PKG OF 9)
14	PA37032	HANDLE SCREW (PKG OF 5)
15	PA37017	TRIGGER ASSEMBLY
16	PA37033	END CAP SCREWS (PKG OF 2)
17	PA37004	END CAP
18	PA37030	FIRING PIN SPRING GUIDE
19	PA38160	FIRING PIN ASSEMBLY
20	PA28111	MECHANISM HOUSING ASSEMBLY
21	PA37012	CHARGE ADVANCE SPRING KIT
22	27516A	TRIGGER SEAR SPRING KIT
23	PA37023	SPALL GUARD
—	309020	DANGER LABEL, BLACK

ORDER BY FAX OR EMAIL**f: 800-529-8680 e: spcustomer.service@itwserviceparts.com**