


YT14 Tractor UT-33017 - Control Panel, Battery And Gas Tank




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context	Note
1	JA992954	DECAL- Start-Stop	1		
2	JA992223	DECAL- Throttle	1		
3	JA992191	CONTROL- Choke	1		
4	JA343060	KEY- Ignition	1		
5	JA993155	DECAL- Cruise Control	1		
6	JA992953	DECAL- Warning	1		
7	JA409036	SCREW- (#10 x 3/4")	4		
8	JA993102	PANEL- Dash	1		
9	JA452002	WASHER- Flat (1/4")	3		
10	JA403908	SCREW- (#10-24 x 3/8")	11		
11	JA992177	CONTROL- Throttle	1		
12	JA990135	SWITCH- P.T.O.	1		
13	JA444782	NUT- Hex Lock (10-24)	3		
14	JA443802	NUT- Hex (1/4-20)	4		
15	JA158992	SWITCH	1		
16	JA992128	SWITCH- Key	1		
17	JA400104	SCREW- (1/4-20 x 1/2")	2		
18	JA375978	BOLT- Steering Support	4		
19	JA995590	SOLENOID	1		
20	JA444306	NUT- Mach (8-32)	4		
21	JA446112	WASHER- Lock (#8)	2		
22	JA446130	WASHER- Lock (1/4-20)	4		
23	JA443102	NUT- Hex (1/4-20)	2		
24	JA992178	CONTROL TOWER	1		
25	JA992011	TANK- Gas	1		
26	JA992235	PAD- Rubber	1		
27	JA992287	STRAP- Upper	1		
28	JA992212	CAP- Fuel	1		
29	JA403910	SCREW- (10-24 x 1/2")	1		
30	00305	DECAL- Gasohol	1		
31	JA992444	BRACKET- Gas Tank	2		
32	JA361117	BUSHING- Gas Tank	2		
33	JA992162	FITTING- Tank	1		
34	JA993276	TUBE- Fuel (7-50")	1		
35	JA408404	SCREW- (1/4-14 x 3/4")	3		
36	JA375994	KNOB- Shut Off	1		
37	JA447218	WASHER- Lock	1		
38	JA443816	NUT- R.H. (7/16-20)	1		
39	JA993993	BRACKET- Fuel Valve	1		
40	JA453013	WASHER	2		
41	JA375995	VALVE	1		

Ref #	Part #	Description	Qty	Context Note
42	JA994469	TUBE- Fuel (28.00") (YT-15)	1	
	JA993277	TUBE- Fuel (6.25") (YT-14, 16 & 18)	1	
43	JA992309	CUSHION- Rubber	1	
44	JA992352	DECAL- Battery	1	
45	JA376124	CABLE- Battery	1	
46	JA444310	NUT	3	
47	JA446116	WASHER- (#10)	4	
48	JA452002	WASHER	7	
49	JA496991	STRAP- Battery	1	
50	JA992202	BATTERY	1	
51	JA497001	BOLT- Battery	2	
52	JA992354	DECAL- Warning	2	
53	JA 400182	SCREW- (5/16-18 x 5/8")	2	
54	JA992444	BRACKET	2	
55	JA447302	WASHER- Int Tooth (5/16")	2	
56	JA443106	NUT- Hex (5/16-18)	2	

YT14 Tractor UT-33017 - Frame, Transaxle And Engine




Ref #	Part #	Description	Qty	Context Note
1	JA408406	SCREW- (1/4-14 x 1")	4	
2	JA392590	BRACKET- Hitch	1	
3	JA446128	WASHER- Lock (1/4")	8	
4	JA443102	NUT- Hex (1/4-20)	6	
5	JA993328	LIMITER- Bracket	2	
6	JA993259	ROD-Dump	1	
7	JA993679	BOLT- Rd.Hd.Sq. Neck (1/4-20 x 4 1/2")	2	
8	JA453013	WASHER (7/16")	2	
9	JA993681	SPRING- Compression	2	
10	JA453009	WASHER- Flat (5/16")	20	
11	JA994573	SPRING (Filter)	1	
12	JA443106	NUT- Hex (5/16-18)	8	
13	JA994574	WASHER (Filter)	1	
14	JA408865	SCREW- (1/4-20 x 9/16")	2	
15	JA994341	FRAME	1	
16	JA994310	CLAMP	2	
17	JA409704	SCREW- Hex (#10-16 x 1/2)	2	
18	JA994565	OVERHAUL- Seal Kit	1	
19	JA994577	SHAFT- Motor	1	
20	JA993272	SHIELD	1	Not used on YT-15 units.
21	JA993275	BULKHEAD	1	Not used on YT-15 units.
22	JA375978	BOLT- (1/4-14 x .44)	2	Not used on YT-15 units.
23	JA446130	WASHER- Lock (1/4-20)	2	Not used on YT-15 units.
24	JA400106	SCREW- (1/4-20 x 5/8") (YT-15)	1	
	JA400106	SCREW- (1/4-20 x 5/8") (YT-14, 16 & 18)	2	
25	JA400198	SCREW- (5/16-18 x 1/4")	2	
26	JA992244	GUIDE- Front Belt	2	
27	JA 400194	SCREW- (5/16-18 x 1 3/4")	2	
28	JA306968	KEY	2	
29	JA992647	BELT	1	
30	JA991071	PULLEY- Drive	1	
31	JA993164	CLUTCH- Brake	1	
32	JA350577	SPACER	1	
33	JA994559	SEAL KIT	1	
34	JA444718	NLA(NO LONGER AVAILABLE)	2	
35	JA993575	PLATE- Retainer	1	
36	JA994561	CHECK VALVE KIT	1	

Ref #	Part #	Description	Qty	Context Note
37	JA994563	BYPASS VALVE KIT	1	
38	JA990128	CLUTCH- Retainer	1	
39	JA446148	WASHER- Lock (7/16")	1	
40	JA400368	SCREW- (7/16-20 x 3)	1	
41	JA400270	SCREW- (3/8-16 x 2)	1	
42	JA339630	IDLER- Inside	1	
43	JA453011	WASHER- Flat (3/8")	7	
44	JA446142	WASHER- Lock (3/8")	8	
45	JA 443110	NUT- Hex (3/8-16)	8	
46	JA328133	BUSHING	1	
47	JA376088	SPRING- Extension	1	
48	JA993254	LINK- Dump	1	
49	JA994575	FILTER	1	
50	JA446134	USE UP03407	2	
51	JA994572	PLUG	1	
52	JA453023	WASHER- Flat (1/4")	2	
53	JA444708	NUT- Lock (1/4-20)	8	
54	JA460014	PIN- Cotter (3/32-3/4")	9	
55	JA994568	UNION ARM	1	
56	JA315344	SPRING	2	
57	JA994569	NAME PLATE	1	
58	JA993286	CAP- Rear Hub	2	
59	JA993157	REAR WHEEL ASSY	2	
60	JA993284	KEY- (1/4 x 2.50)	2	
61	JA142190	BEARING ASSY.	1	
62	JA460048	PIN	1	
63	JA458039	RING- Snap	4	
64	JA453017	NLA(NO LONGER AVAILABLE)	2	
65	JA400202	SCREW- (5/16 x 3")	4	
66	JA400268	SCREW- (3/8-16 x 1 3/4")	3	
67	JA336222	PULLEY	1	
68	JA993295	REINFORCEMENT	1	
69	JA446136	WASHER- Lock (5/16")	2	
70	JA993217	ARM & LUG	1	
71	JA993257	BRACKET- Rotation Control	1	
72	JA408870	SCREW- (5/16-18 x .88)	1	
73	JA432005	SCREW- Set (1/4-20 x 1/2")	1	
74	JA452006	NLA(NO LONGER AVAILABLE)	3	
75	JA993072	ROD	1	
76	JA994333	PIVOT- Bracket & Arm	1	
77	JA400188	HEX BOLT- (5/16-18 x 1")	3	

Ref #	Part #	Description	Qty	Context Note
78	JA400108	USE 80052	3	
79	JA400184	SCREW- (5/16-18 x 3/4")	4	
80	JA993161	CONNECTOR	1	
81	JA993171	SLEEVE	1	
82	JA993677	SCREW- (m6 x 1 x 12mm)	1	
83	88120	SCREW- (m8 x 1.25 x 50mm)	1	
84	JA993253	BRACKET- Pivot	1	
85	JA400186	SCREW- (5/16-18 x 7/8")	6	
86	JA406005	SCREW- (10-24 x 5/8")	2	
87	JA993567	GUIDE BELT	1	
88	JA993216	KEY	1	
89	JA993676	SCREW- (m8 x 1 1/4 x 120mm)	1	
90	JA992834	PULLEY	1	
91	JA992646	FAN	1	

YT14 Tractor UT-33017 - Lift, Brake And Clutch Linkage




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA993298	LIFT BAR ASSY.	1	
2	JA446142	WASHER- Lock Hvy. (3/8")	8	
3	JA460014	PIN- Cotter (3/32 x 3/4")	9	
4	JA376094	BOLT- Shoulder	2	
5	JA461363	PIN- Roll (1/8 x 1")	2	
6	JA343497	KNOB Shift Lever	1	
7	JA142186	HANDLE ASSY.	1	
8	JA993291	HANDLE LIFT	1	
9	JA461347	PIN- Groove	1	
10	JA351587	BUSHING	4	
11	JA452006	NLA(NO LONGER AVAILABLE)	3	
12	JA 443110	NUT- Hex (3/8 x 16)	8	
13	JA181969	BRACKET- Brake Spring	1	
14	JA993296	REAR LIFT & BUSHING	1	
15	JA453020	WASHER	2	
16	JA461383	PIN- Roll	6	
17	JA453011	WASHER- Flat (3/8")	2	
18	JA446128	WASHER- Lock (1/4")	2	
19	JA444718	NLA(NO LONGER AVAILABLE)	8	
20	JA434027	SCREW- Socket	3	
21	JA376098	ROD- Idler Act	1	
22	JA376066	BUSHING- Snap	1	
23	JA993242	LEVER- Clutch	1	
24	JA444782	NUT- C'Lock (#10-24)	7	
25	JA453009	WASHER- Flat (5/16")	9	
26	JA994331	ARM- Deactivating	1	
27	JA993138	ROD- Brake	1	
28	JA993292	FLANGE & ROD ASSY.	1	
29	JA993289	CABLE- Lift	2	
30	JA376073	PULLEY- Lift Cable	2	
31	JA376015	RETAINER- Cable	2	
32	JA376092	SPRING- Compression	1	
33	JA400106	SCREW	2	
34	JA993243	BRAKE LEVER	1	
35	JA344895	PEDAL- Clutch	1	
36	JA375810	NUT- Push	1	
37	JA993338	DECAL- Park Brake	1	
38	JA991560	SWITCH- Safety	1	
39	JA376102	SPRING- Comp Brake	1	
40	JA993241	ARM- Brake/Clutch	1	
41	JA443106	NUT- (5/16-18)	4	
42	JA375431	BOLT- Shoulder (5/16-18)	2	
43	JA402776	SCREW- Slotted Truss Hd (#4-40 x 1)	2	
44	JA353077	TIP	1	

Ref #	Part #	Description	Qty	Context Note
45	JA994327	LATCH & LEVER	1	
46	JA446136	WASHER- Lock Hvy (5/16")	2	
47	JA444302	NUT- Hex (#4-40)	2	
48	JA443102	NUT- Hex (1/4-20)	4	
49	JA376061	BRACKET	1	
50	JA375978	SCREW- (1/4-14 x .44")	2	


YT14 Tractor UT-33017 - Steering Linkage



Ref #	Part #	Description	Qty	Context Note
1	JA990346	WHEEL- Steering	1	
2	JA461387	PIN- Roll	1	
3	JA993162	BELLOW- Steering	1	
4	JA339632	SHAFT- Steering Wheel	1	
5	JA400104	SCREW- (1/4-20 x 1/2")	2	
6	JA376074	BEARING- Steering Shaft	1	
7	JA346133	BUSHING	1	
8	JA375970	WASHER- Front Hub	1	
9	JA339629	PINION- Steering	1	
10	JA992581	WASHER	2	
11	JA 443110	NUT- Hex (3/8-16)	1	
12	JA446130	WASHER- Lock (1/4-20)	2	
13	JA443102	NUT- Hex (1/4-20)	4	
14	JA461383	PIN- Roll	1	
15	JA376108	SPACER- Steering	1	
16	JA142203	SUPPORT- Steering	1	
17	JA443826	NUT- (5/8-11)	1	
18	JA376121	SPACER- Steering Gr.	1	
19	JA465006	BALL- .312 Dia.	1	
20	JA311555	BUSHING	2	
21	JA392599	GEAR- Steering	1	
22	JA 443118	NUT- (1/2-13)	1	
23	JA446154	WASHER- Lock hvy. (1/2")	1	
24	JA453017	NLA(NO LONGER AVAILABLE)	1	
25	JA400186	SCREW- Hex (5/16-18 x 7/8")	4	
26	JA453009	WASHER- Flat (5/16")	8	
27	JA446136	WASHER- Lock (5/16")	8	
28	JA443106	NUT- Hex (5/16-18)	4	
29	JA376067	ROD	1	
30	JA453022	WASHER- Flat (3/4")	5	
31	JA313820	SPACER- Axle	8	
32	JA460064	PIN- Cotter (1/4 x 1 1/2")	1	
33	JA453023	WASHER- Plain (1/4")	1	
34	JA408878	SCREW- (1/4-20 x 3/4")	1	
35	JA461408	PIN	1	
36	JA376065	BUSHING- Spindle	4	
37	JA142188	AXLE- Front	1	
38	JA471225	FITTING- Grease	2	
39	JA992616	SPINDLE- L.H.	1	
40	JA310084	BEARING	2	
41	JA400272	SCREW- (3/8-16 x 2 1/4")	1	

Ref #	Part #	Description	Qty	Context	Note
42	JA992614	BAR- Tie	1		
43	JA992617	SPINDLE- R.H.	1		
44	JA375411	WASHER	2		
45	JA376085	BOLT- Tie Bar Mtg.	2		
46	JA446142	WASHER- Lock (3/8")	2		
47	JA990345	CAP- Steering Wheel	1		
48	JA992368	ARM- Steering	1		
49	JA 444762	NUT- Centerlock (3/8-16)	1		
50	JA320790	KEY	1		
51	JA376115	SPACER- Balljoint	2		
52	JA376064	JOINT- Ball	2		
53	JA316802	CAP	2		
54	JA446128	WASHER- Lock (1/4")	4		
55	JA312398	WASHER- Wheel Retaining	2		
56	JA994329	BRACKET & PAD	2		
57	JA400106	SCREW- (1/4-20 x 5/8")	5		
58	JA400268	SCREW- (3/8-16 x 1 3/4")	3		
59	JA376114	SPACER- Balljoint	1		
60	JA339631	PITMAN ARM	1		
61	JA460040	PIN	2		
62	JA992252	SCREW- (3/8-16 x 1 1/2")	1		
63	JA443112	NUT- (3/8-24)	3		
64	JA992131	TUBE- Drag Link	1		
65	JA181964	RIM & TIRE ASSY.	2		

YT14 Tractor UT-33017 - Transaxle Assemblies




Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context Note
1	JA994545	AXLE & SHAFT (R)	1	
2	JA994543	WASHER- (20 x 29.5 x 2)	2	
3	JA994547	RING- (15)	2	
4	JA994544	AXLE- Shaft	1	
5	JA994546	NEEDLE	2	
6	JA994548	SEAL	2	
7	JA994549	DRUM- Brake	1	
8	JA994557	RING- (10)	1	
9	JA994554	SHOE- Brake	2	
10	JA994555	SPRING	1	
11	JA994553	BRAKE- Assy (CB-1)	1	
12	JA994556	BRAKE COVER ASSY.	1	
13	JA994558	BOLT- (w/washer) (8 x 20)	4	
14	JA994541	BEARING (6203)	1	
15	JA994538	FINAL PINION ASSY.	1	
16	JA994542	BEARING- (6302)	1	
17	JA994505	CASE- Lower	1	
18	JA994516	SCREW- Tapping (8 x 35)	6	
19	JA994502	MISSION CASE	1	
20	JA994515	SCREW- Tapping (8 x 30)	14	
21	JA994509	PACKING- (P16)	1	
22	JA994507	PLUG- (14)	1	
23	JA994504	VENT VALVE ASSY.	1	
24	JA994503	UPPER CASE	1	
25	JA994529	GEAR- Differential	2	
26	JA994506	PLUG	2	
27	JA994508	PACKING	2	
28	JA994532	PINION- Differential	2	
29	JA994539	GEAR- Final (43)	1	
30	JA994535	BEARING- (6006)	2	
31	JA994531	SHAFT- Diff. Pinion	1	
32	JA994536	BOLT- (6 x 30)	6	
33	JA994514	PACKING- (G60)	1	
34	JA994518	WASHER- (.30 x 42 x 2)	1	
35	JA994527	BEARING- (6004)	1	
36	JA994519	MOTOR GEAR ASSY	1	
37	JA994521	MAIN SHAFT	1	
38	JA994528	BEARING- (6202)	2	
39	JA994523	SHAFT- Idle	1	
40	JA994525	WASHER- Thrust	2	
41	JA994524	GEAR- (24)	1	

Ref #	Part #	Description	Qty	Context Note
42	JA994522	SHIM- ASSY.	1	
43	JA994501	SEALANT	1	
44	JA994526	NEEDLE- (20 x 26 x 12)	1	
45	JA994517	SCREW- Tapping (8 x 45)	4	
46	JA994537	NUT	6	
47	JA994534	WASHER	6	
48	JA994533	CASE	2	

YT14 Tractor UT-33017 - Wiring Diagram



Rendered by LeadVenture, Inc.

Ref #	Part #	Description	Qty	Context	Note
1	JA376124	CABLE- Battery, (-) Black			
2	JA990890	HARNESS- Headlights			
	JA993278	WIRING HARNESS (Main) (YT-14, YT-16, & YT-18)			
	JA994379	WIRING HARNESS (Main) (YT-15)			